



SmartSDR™ for Windows v1.10.16 Release Notes

February 21, 2017

What's New in SmartSDR v1.10.16

SmartSDR for Windows v1.10.16 is a general release intended for use with the FLEX-6300™, FLEX-6500™, FLEX-6700R™ and FLEX-6700™ software defined radios that include new features and address software defects identified in the previous 1.10.15 BETA version of SmartSDR for Windows. Please consult the [SmartSDR Software Users Guide](#) for details on using the new and updated features of SmartSDR for Windows for the most optimal operating experience.

A cumulative and inclusive **ChangeLog** file listing all of the modification to SmartSDR for Windows, SmartSDR CAT, DAX, the firmware and SmartSDR for Maestro can be found in the Program Files\FlexRadio Systems\SmartSDR\Documentation folder.

Updated 60m Band for Sweden: Radios that have been updated for the Swedish region are now able to use the new 60m band allocation when running SmartSDR v1.10.16 and greater (Update #4389).

Intermittent Radio Crashes after Multiple Client Connections: A defect was inadvertently introduced into a previous version of SmartSDR that would result in the radio locking up (crashing) after a certain number of client connections were made to the radio (Defect #4426).

USB Cable LDPA Transmit Antenna Fix: When using a USB Cable connection configured for the LDPA, the LDPA would key up to transmit when a different slice was designated as the transmit slice. This issue has been resolved (Defect #4446).

XVTR Power by Band Persistence Fixed: When using XVTR bands, power level settings by band was not be saved properly. This issue has been resolved (Defect #4410).

Radios failing to Reboot after Firmware Upgrade: A condition that would sometimes prevent a radio from completing a firmware update and requiring a manual reboot has been resolved (Defect #4492).

Important Release Details

The following information is specific to SmartSDR v1.10.16. Please read the following Important Release Details before installing this version of SmartSDR for Windows or SmartSDR for Maestro.

Requirements and Recommendations for Installing SmartSDR for Windows 1.10.16

The previous 1.10.8 BETA version of SmartSDR for Windows contained an updated version of the D-Star waveform (v1.1.0) functionality. It is recommended that you manually uninstall and then install the latest version of the D-Star application as soon as you have upgraded to SmartSDR v1.10.16 if you had not installed SmartSDR v1.10.8 BETA or SmartSDR v1.10.15 BETA. Once the new D-Star application is installed, you will need to manually uninstall the old waveform from the radio and install the updated waveform. For detailed instructions on how to uninstall and install the D-Star application, please refer to the website link to the D-Star Waveform How To Guide in the [SmartSDR Documentation Available at www.flexradio.com](#) section below.

If you operate your radio remotely, please read this before upgrading. As a result of correcting defect #4046 in SmartSDR v1.10.8 BETA, where the power LED would incorrectly indicate the presence of a GPSDO, the setting for the Remote On feature has been reset to its default state (disabled). If you are using the Remote On feature of the radio and did not upgrade to SmartSDR v1.10.8 BETA or 1.10.15 BETA, you will need to change it back to enabled once you have upgraded to SmartSDR v1.10.16.

Upgrading the radio remotely may result in the radio not rebooting after the upgrade if the Remote On feature is required.

With the previous version of SmartSDR for Windows v1.10.8, a new FlexVSP driver was installed. This new driver is less susceptible issues after a Windows 10 update. The new FlexVSP driver will automatically be installed as part of the installation process if an upgrade is needed. **There is no need to uninstall the existing FlexVSP driver before installing SmartSDR v1.10.16.** You may notice that the installation process is taking a little longer than usual to complete and this is due to installing the new FlexVSP driver. **It is highly recommended that you reboot the PC when prompted at the end of the SmartSDR for Windows installation process.**

Best Practices for installing a new version of SmartSDR for Windows

The following “Best Practices” are highly recommended to ensure a seamless and trouble-free upgrade to SmartSDR for Windows.

In preparation for the upgrade to SmartSDR for Windows, *always* backup your current Global and TX Profiles. Please refer to the SmartSDR for Windows Software User’s Guide for detailed instructions related to exporting your profiles to a file on your PC. Whenever you upgrade to a newer version of SmartSDR for Windows, there is a database conversion program that runs automatically to convert an older version of the Profile database to the new format or schema. *However, the reverse is not true.* If you have to revert to a previous version of SmartSDR for Windows, the older version will not be able to downgrade the database schema. In order to recover your previously created profiles after a software version downgrade, an import of profile data created using the version of SmartSDR for Windows you are downgrading to is required for proper operation of your radio.

Ensure your Windows operating system is up to date before installing SmartSDR for Windows. The proper operation and installation of SmartSDR for Windows and its associated drivers rely on having an up to date Windows operating system including the root security certificate. It is highly recommended that you run Windows Update and install all mandatory and optional updates before installing SmartSDR for Windows.

Shut down all third-party programs running on your PC that utilize a sound card. If necessary, the SmartSDR for Windows installer may install or upgrade the virtual sound card DAX drivers. As part of this process, it will uninstall the older drivers first. If there is an application open on your PC that is using one of the DAX drivers, uninstalling of the existing DAX driver will fail which may result in issues installing the updated DAX drivers. Examples of these types of programs include, but are not limited to digital mode programs, Windows Media Center, web browsers and audio players.

Shut down all third-party programs utilizing virtual com ports. The installation of SmartSDR CAT may also install new or recreate existing virtual com ports as part of the installation process. Please shut down any program that may use the FlexVSP virtual serial port driver. Examples of these include but are not limited to any digital mode programs, loggers, spotting programs and hardware devices that interface through a virtual com port

Managing SmartSDR for Windows installed on other PCs connected to your network. If you have installed SmartSDR for Windows on other PCs that are connected to the same network as the FLEX-6000, these PCs may be running SmartSDR CAT and DAX since these applications auto-start when the PC is booted. Running these applications while upgrading SmartSDR for Windows may result in installation issues, therefore it is recommended that these PCs be shut down or remove SmartSDR from Windows from the PCs prior to installing a new version of SmartSDR for Windows. In addition, these PCs will need to be upgraded to the same version of SmartSDR after the FLEX-6000 firmware has been upgraded to ensure a consistent operating experience.

Power off the FLEX-6000 before installing new SmartSDR for Windows on your PC. To ensure a seamless upgrade of the entire SmartSDR software ecosystem, it is recommended that you power off your radio before installing the SmartSDR for Windows software on your PC.

Power Cycle your Radio after upgrading the firmware. When upgrading the radio firmware, there may be updates to several of the internal subsystems. Powering off the radio, disconnecting it from DC power for several seconds, reconnecting DC power and powering up the radio after updating the firmware ensures that all processors reboot properly.

What to do if the firmware updates do not finish after 5 minutes? On rare occasions, the FLEX-6000 may not respond to the reboot signal after doing a firmware update. If the radio has not successfully completed the firmware updates after 5 minutes, power off the radio by pressing and holding the power button until the radio shuts down. Remove the DC power source from the radio to power down all processors. Restore DC power and reboot the radio. The firmware update should complete normally.

Uninstalling Previous Versions of SmartSDR for Windows – Is It Necessary?

This is a frequently asked question that does not have a simple “yes/no” answer. **In general, the answer is no, but there are special considerations to consider.**

Each version of SmartSDR for Windows is installed in such a manner that running a previous version is a simple matter of running an older version of SmartSDR for Windows and allow the radio firmware to downgrade automatically. This method of installing unique versions of software on your PC rather than upgrading a previous version allows for an easy and convenient way to switch to a previous version if you so desire.

Unfortunately, there are exceptions that result in release specific caveats. In the case of SmartSDR for Windows v1.10.16, there are **no** release specific caveats that require removing previous versions of SmartSDR for Windows.

In addition to any release specific caveats, there are shared components of the SmartSDR ecosystem used by multiple versions of SmartSDR for Windows. Operationally this typically does not result in any issues, but if a previous version of SmartSDR for Windows is uninstalled while there is a newer version installed, the possible removal of one or more of these shared components may make newer versions of SmartSDR for Windows inoperable. **Therefore if you desire to uninstall older versions of SmartSDR for Windows, it is highly recommended that you uninstall all older versions of SmartSDR for Windows before installing a new version of SmartSDR for Windows.**

Removing the DAX and FlexVSP drivers are not recommended unless explicitly instructed to do so in the Release Notes or by FlexRadio Support.

If you chose to uninstall several previous versions of SmartSDR for Windows prior to installing a new version, you may want to perform a comprehensive removal of the SmartSDR ecosystem from your PC. This is not a requirement, but it will ensure that all SmartSDR for Windows applications and hardware drivers have been removed allowing for a clean install of a more recent version of SmartSDR.

This is a multi-step process that is outlined in the HelpDesk article [How to do a Complete uninstall of SmartSDR for Windows from your PC.](#)

Known Issues

1. In some situations, due to some deficiencies with Windows, the FlexControl may choose a COM port that has already been assigned to a virtual COM port or another device. It may be necessary to move the FlexControl to a different COM port and disconnect/reconnect the FlexControl to resolve this issue. Follow these instructions: <https://helpdesk.flexradio.com/hc/en-us/articles/202479329-How-to-Change-the-Com-Port-Assignment-for-a-FlexControl>
2. There is a known issue (#4394) where the current virtual serial port driver may cause unused COM ports to appear as “In-Use” on your PC. We are actively working to resolve this issue.
3. FLEX-6700 only: There is a known issue (#280, #1527) where changing bands on one panadapter may change the frequency of another panadapter when going to or from 2m (or an XVTR using 2m as an IF). This happens due to hardware constraints that require each Antenna to be on only one of 2 possible Nyquist zones (below or above 122.88 MHz) and an interaction with persistence when recalling the antenna selection of the selected band. One way to work around this issue is to use the Band buttons instead of setting the Antenna on the Panadapter or Slice, and then entering the desired frequency into the Slice in order to tune into (or out of) the 2m band (or an XVTR using 2m as an IF).

SmartSDR Documentation Available at www.flexradio.com

The following documentation and how to guides for SmartSDR v1.10.16 are available as a convenient download from the FlexRadio website.

SmartSDR for Windows Software User’s Guide

<http://www.flexradio.com/downloads/smartsdr-software-users-guide-pdf/>

FLEX-6000 Signature Series Hardware Reference Manual

<http://www.flexradio.com/downloads/flex-6000-hardware-reference-manual-pdf/>

FLEX-6000 Signature Series Quick Start Guide

<http://www.flexradio.com/downloads/flex-6000-family-qsg-single-page-pdf/>

SmartSDR CAT User Guide

<http://www.flexradio.com/downloads/smartsdr-cat-user-guide-pdf/>

D-STAR Waveform How to Guide

<http://www.flexradio.com/downloads/d-star-waveform-how-to-guide-pdf/>

FreeDV Waveform How to Guide

<http://www.flexradio.com/downloads/freedv-waveform-how-to-guide-pdf/>

USB Cable Interface Guide

<http://www.flexradio.com/downloads/usb-cable-interface-guide-pdf/>

Obtaining Technical Support

If you encounter any issues installing or operating SmartSDR for Windows with FlexRadio Systems' Signature Series software defined radios, please use our on-line Community (<https://community.flexradio.com/>) to query for information about SmartSDR for Windows and the FLEX-6000. If you need assistance using the Community, please refer to the community topic "[How to use the FlexRadio Systems Support Community](#)".

If you are unable to find an existing answer to your issue on the Community, please contact FlexRadio Systems technical support by opening a HelpDesk support ticket on-line at <https://helpdesk.flexradio.com/>

For details on how to submit a HelpDesk support ticket, please refer to the following URL: <https://helpdesk.flexradio.com/hc/en-us/articles/202118688-How-to-Submit-a-Request-for-Technical-Support>.

Hours of Operation: Our Technical Support engineers are available Monday-Friday from 9:00am-5:30 pm Central Time. If you contact Support after business hours, on a holiday or weekend, we will respond to your request for assistance during regular business hours in the order your HelpDesk ticket was received.

Copyrights and Trademarks

© 2005-2017 FlexRadio Systems. All rights reserved.

FlexRadio Systems is a registered trademark of Bronze Bear Communications, Inc. DBA FlexRadio Systems.

FLEX-6300, FLEX-6500, FLEX-6700, FLEX-6700R, Maestro, FlexControl, PowerGenius XL, SmartSDR, SmartSDR for Windows, SmartSDR for iOS, SmartSDR CAT, DAX, TNF, WNB, the SmartSDR "spectrum" (logo) and the FlexRadio Systems "wave" (logo) are trademarks of FlexRadio Systems.

FlexRadio Systems
4616 W. Howard Lane
Suite 1-150
Austin, TX USA 78728
+1 (512) 535-4713
www.flexradio.com